




I AM
ACCURATE



**Innovation
Quality
Performance**

PH) **Prodont Holliger**



SOLDERING SOLUTION FOR

- ✓ **Cast Partial Frame Work.**
- ✓ **Rocking Bridges**
- ✓ **Suck Back Holes / Porosties in Castings**
- ✓ **Prefabricated Precision Attachments**
- ✓ **Ceramic built up is possible on soldered joint area**

Helpfull Hints :

- ✓ **To avoid heat absorption from the soldering joint, keep the solder investment block as small as possible**
- ✓ **We recommend preheating of the soldering block for approx. 15 min at 500 C before soldering**



**Protect your eyes — Wear safety goggles !
Use protective equipment when soldering !**